



UTT10 Structural Attachment Structure –attachment Fitting

Function: Designed for bracing pipe against sway and seismic disturbance. The pipe attachment component of a sway brace system used in conjunction with a UTT Manufacturing structural attachment fitting, and joined together with a bracing pipe element forms a complete sway brace assembly. Sway brace assemblies are intended to be installed in accordance with NFPA 13 and the manufacturer's installation instructions.

Type: Sprinkler Pipe Sch 10,Sch 40,GB/T 3091,JIS G3454
Size: One size fits braced pipe up to 8", with 1/2" bolt hole for structure.

Material: Carbon steel

Finish: Electro - galvanized

Approvals:

| UL Maximum Design Load | | | | | |
|------------------------|------|--------|----------|-------|--|
| Brace Member | lbs. | kN | Wt. Each | | |
| | | | lb. | kg | |
| 1" SCH40 pipe | 1885 | (8.38) | 1.54 | (0.7) | |

| FM Maximum Design Load | | | | | | |
|------------------------|---|--------|---|--------|----------|-------|
| Brace Member | Horizontal load ratings installation angle 30° –44° | | Horizontal load ratings installation angle 45° –59° | | Wt. Each | |
| | lbs. | kN | lbs. | kN | lb. | kg |
| 1" SCH40 pipe | 1490 | (6.62) | 1980 | (8.80) | 1.54 | (0.7) |



Install:

The connection mode of base part connected with the building. The connection between the base part and the building is completed. The accessories connected with the base part is sch40 1-inch pipe. The pipe must be clamped to the bottom of the base part, then fixed with the shear bolt. Tighten the shear bolt until heads break off. Tighten the shear bolt until heads break off.